

+F FS030W



Contact

Phone Number:
03-6812-1288
(weekday 10am ~ 6pm)

e-mail:
info@luckywifi.net

*Customer is responsible for the charge for a telephone call.

*Before contact us, please read "trouble shooting" on the reverse side.

Only for Domestic

Return Address


Terralink Inc.
Meisho MG building 8F, 1-47-1 Higashi Ikebukuro,
Toshima-ku, Tokyo, 170-0013, Japan

Extend Rental Period

- You can apply online with Rental Extension to extend your rental period.
- We apologize for not being able to comply with your extension request over the phone.



Parts and Functions



- Strap Hole
- Display
 - Power on → Press Power switch for over approximately three seconds.
 - Power off → Press Power switch for over approximately three seconds.
 - Press power switch when the power on, change the screen.
 - It works as "OK" button
- Power switch
- LED

Lightning colour	Status
Red-flickering	SIM card not inserted, PIN Lock, low battery, profile error, out of range
Red-lightning	Charging
Green-lightning	LTE/SG connecting, Fully charged
Orange-lightning	Updating software

- micro USB connector
 - Connect to micro USB cable
 - Docking with cradle
- WSP button
 - Press WSP button for over approximately three seconds when the power is on, WSP status.
- Reset button
 - Press reset button when the power is on.
 - Rebooting → Press reset button for over approximately five seconds to reset settings to defaults.
- micro SIM card slot
- battery pack

Power on / off

- Press power switch for over three seconds when the power is off.
Lights when turning on the power
- Press power switch for over three seconds when the power on.
Lights out when turning off the power

Charging

- Use supplied USB cable**
Insert USB cable into External Device Port and USB cable to a computer.
- Use AC charger**
Insert USB cable into EXternal Device Port, USB cable into USB connector of AC charger, and power plug of AC charger to AC outlet.

Display (Home screen)


Display Wi-Fi router's status.



- Home screen
- WLAN connecting
- WLAN QR connecting
- Profile
- Bluetooth

SSID and primary key

Setting for primary SSID and password, confirm from "WLAN connecting information."




◆ Connecting Windows PC (Windows 10)

*For security key, please read "SSID and primary key"

- 1 Activate PC WLAN function
- 2 In task tray click, "Network settings" appears.
- 3 Select Wi-Fi name (FS030W_PXXXX) →click "Connect"



- 4 Enter password → "NEXT"



- 5 Checking WLAN connected

◆ Connecting PC (Mac)

*For security key, please read "SSID and primary key"

- 1 In Apple menu, "System Preferences" →"Network"
- 2 "Wi-Fi" → "Turn Wi-Fi on"
- 3 In "Network Name" pulldown list, select Wi-Fi router's Wi-Fi name (FS030W_PXXXX)
- 4 Enter password (Primary key) in "Password" →Click "Remember this network"



*WLAN connection counter number on Display increases by one.

- 5 Checking WLAN connected.

*If a message "Can't detect preferred Network" appears, take off the checkmark "Confirm before connecting to new network"

◆ Connecting Android Device

*For security key, please read "SSID and primary key"

*Connecting general android device. This section describes setup operations for WPA security settings.

- 1 Activate Android device →In menu "Setting"→"Wi-Fi"
- 2 Tap Wi-Fi router's SSID(FS030W_PXXXX)
- 3 Enter Primary Key in "password" correctly



*WLAN connection counter number on Display increases by one.

- 4 Checking Wi-Fi LAN connected.

*Operation steps vary by Android device. For details, refer to Android device user guide.

◆ Connecting iPhone / iPod touch / iPad (iOS 10)

*For security key, please read "SSID and primary key"

- 1 Activate iOS device "Settings"→"Wi-Fi"
- 2 Tap Wi-Fi name (FS030W_PXXXX)
- 3 Enter password (Primary key) →"Join"



*WLAN connection counter number on Display increases by one.

- 4 Checking Wi-Fi LAN connected.

◆ Trouble Shooting

*Please confirm before inquiry


【Wi-Fi router is not working, Unable to charge, connect】
Please restart the router.

【Unable to connect Internet Wi-Fi】
Please be sure Wi-Fi router function is turned on.
Please be sure, you entered password correctly.

If problem persists, reset Wi-Fi router.

◇How to Reset Wi-Fi router

- 1.Press battery cover to slide as marked ▶, and lift it up to remove it.
- 2.Press reset button over approximately five seconds when the power is on.



【Internet connection fails】

If signal reception is poor or fails, move to where signal is strong, then reconnect. Also please restart the router and connecting devices.

【Communication speed is slow】

Using TV, radio or microwave oven may cause interference signal reception of Wi-Fi router. Use them apart from Wi-Fi.

【Wi-Fi router is inoperative】

Remove Battery →Insert Battery →Power on after a while